

How to Use Warming Oven

1. To turn on, press the power button at the bottom left.
It will take about 45 minutes for the warmer to heat up.
2. Turn the dials all the way to 9.
3. Try not to open the door too often or the heat will escape.
4. Be sure to shut it off when finished.